

Perini

Installation Guide

This is a one of a kind, hand crafted and unique concrete design that is made to last, and with a bit of care and love you will have this forever.

We recommend using the correct waste is purchased for your basin – Our recommendation is our ADP Universal 32-40mm pop up waste (comes in Matte Black, Matte White and Chrome), or any other waste that suits.

Ensure no water is trapped under the sink, a silicone bead around the perimeter of the base of the basin is required to ensure no water gets under the basin. If water does get trapped through poor installation water marks can appear.

Ensure the waste is tightened – Hand tight only.

Ensure the waste is siliconed in and all silicone is left to dry for at least 24 hours prior to use.

Warm soapy water is the best way to clean your basin, no harsh abrasive material to be used nor cleaning products are used.

Ongoing Maintenance - WAX: Your beautiful basin comes already sealed and waxed. This waxing process should be done every 3-4 months to ensure the protection of the sealer and against any staining. See Care and Maintenance.

Care and Maintenance of your Handcrafted Concrete Basin

Made from only the best products, this concrete has been sealed with the best, waxed and cured and tested before leaving our factory to ensure its excellent quality in your bathroom.

Only a little common sense and care is needed in caring for your basin: Remembering that our concrete is both water tolerant and stain resistant but not water and stain proof. Ensuring you wipe and clean as you use is essential to the ongoing care of your beautiful basin. Over time your basin will gain character, as it is a natural ageing product.

Wipe as you go, using a soft damp cloth to wipe it down

If you encounter stubborn stains, use a mild non-abrasive cleaner.

Avoid exposure to products with high PH levels such as jiff and bleach, avoid exposure to paint strippers, nail polish remover and hair dye. Rinse immediately to neutralise the effect, and then follow usual cleaning procedure using a PH neutral cleaning agent.

Avoid exposure to high impact, especially on the edges.

Stubborn Stains and Dried Spills:

Our high-end sealers provide great resistance to most commonly used items used in the bathroom. But please note: if left for an extended period, stains may occur - so ensure you wipe down as you go. A wet cloth is recommended for any stubborn stains. If needed use a non-acidic and non-abrasive cleaner and rinse well with water. Avoid forceful scrubbing as this may result in a loss of shine and remove the protective sealer.

DO NOT leave on your basin - toothpaste, mouthwash, hair dye or sunscreen, oil based products or makeup.

DO NOT fill your basin with boiling water and leave for extended periods of time. Your basin is designed for washing not soaking.

As a mild and gentle cleaner, we like to use a damp microfibre, and combining dishwashing liquid - 2 Tablespoons to 1 litre of water, this works as a great general cleaner!

Direct Sunlight: Our concrete basins are a suitable product to be used outdoors, our concrete colours are all UV resistant, and the colour is throughout the entire concrete piece, but exposure to direct sunlight and weather may result in a slight colour change over an extended period.

Heat Resistance: Placing hot items such as a hair straightener directly onto your polished concrete basin is not recommended. Although it is heat resistant, excessive localised heat may result in damage to the concrete sealer or may have thermal shock.

Scratches, Cracks and Edge Chipping: Like all materials, overtime the sealer on concrete basins may develop scratches and abrasive marks. To minimise this, follow the waxing procedure to ensure your basin looks beautiful.

As with all basins, concrete is susceptible to chipping and cracking with improper use. Avoid impact on edges and the surface with hard objects. Areas around cutouts are weak points and can form small hairline cracks. The damage is aesthetic and not structural. But structural cracks, the product will be replaced. Please note, hairline cracks are not common but may occur. Please ensure you follow the installation process correctly.

Ongoing Maintenance - Waxing Instructions:

Using only a slightly damp microfibre, wipe on a 20-50 cent size of wax on the internal surface, applying in a circular motion that overlaps to ensure no missed areas. Leave for a few minutes and then gently buff off in light circular motions with a dry microfibre. Repeat every 3-4 months or as required

Please note: Care and Maintenance Guide must be read in conjunction with Warranty and Installation Guide.